


with the AgGPS® EZ-Boom® 2010 System Quick Reference Card

CONNECTING THE SYSTEM

Once the AgGPS® EZ-Boom® 2010 automated application control system has been professionally installed, add the FmX™ integrated display as shown:



RUN SCREEN LAYOUT

Status items – These are at the top of the run window and are visible all the time. Tap any text item to toggle to a single status item in a larger font.

Vehicle view icon – Tap to toggle between overhead and trailing views.

Information icon – Tap to display a larger amount of permanent text for operations relating to the display.

Zoom and Pan icons – Tap to show zoom and pan function buttons.

Coverage theme – Panel displays the coverage and variety tracking settings. You can view height, coverage/overlap, variety, and GPS quality.



Home – Use to close a field and return to the start window.

Run icon – Tap to get started in a field.

Active plug-in tabs – Show status and control functions for the applications connected to the FmX integrated display. Tap the Tab icon to change the tab.

Tank refill icon – Tap to open the Tank tab where you can select tank refill options.

Engage panel – Contains the engage controls for plug-ins such as Autopilot™, TrueTracker™ implement steering, and FieldLevel II. You can also control for coverage logging.

Boom sections – Shows the status of the individual boom sections.

SETTING UP THE EZ-BOOM SYSTEM ON THE FmX DISPLAY

Notes:


For more information on system calibration and settings, see the EZ-Boom documentation.

If you have any questions regarding settings, tap the **Tips** button or refer to the FmX Integrated Display User Guide.

Setting up the Implement


To set up the implement for the EZ-Boom system, do the following:

1. In the Home screen, tap the *Run* icon.
2. Tap the **Switch** button next to *Implement*.
3. Do one of the following:
 - Tap **New** to create a new implement.
 - Select an existing implement.
4. When creating a new implement, enter a name for the implement and then tap **OK**.
5. Complete the Implement Setup wizard: Complete each screen and then tap **Next** to proceed to the next screen:
 - a. Select the required implement from the *Operations* drop-down list.
 - b. In the *Guidance* tab make the required entries in all the fields:



- c. Complete the *Geometry* tab if you are using the TrueGuide™ implement guidance, implement monitoring, or the TrueTracker™ implement steering system. Enter the Antenna Front/Back Offset, Antenna Left/Right Offset, and the Antenna Height.


- d. In the *Overlap* tab make the required entries in all the fields:



- Adjust the *Start Overlap* and *End Overlap* based on when the sprayer turns on and off as it enters or leaves the applied area:
 - Adjust *Allowable boundary overlap* for the amount of overlap a section has to be outside the boundary before shutting off.
 - Adjust *Allowable side-to-side coverage overlap* for the amount of side-to-side overlap before shutting off.
 - *Infill Boundary* controls where material stops being applied when approaching the headlands: *Inner* allows the headland to be applied last. *Outer* allows material to be applied to the field boundary if material was not previously applied in the headlands.
- e. In the *Extras* tab, set up the Variety (using the **Variety Setup** button) and the **Remote Log Switch**.


Note: The *Remote Log Switch* is not used with the EZ-Boom system.

6. Select and then add the EZ-Boom plugin if this is not already installed and then tap **OK**:



Setting Boom Switching and Rate Control


1. In the *Configuration* screen, select *EZ-Boom* and then tap **Setup**.
2. Select the required *Boom Switching* and *Rate Control* options and then tap **OK**:



If *Boom Switching* is **on**, the EZ-Boom system controls the boom sections based on the coverage map. If *Rate Control* is **on**, the system controls the application rate.

Setting Valve Latency

1. Tap the *Boom* tab:




2. Do one or more of the following:

- Set the **Section Signal**: This setting controls whether the system sends a high or a low signal to close a section valve. Select **Standard** (Sprayers) when using:
 - Motorized and solenoid valves (typically used in sprayers)
 - A Tru Count inverter box
 Select **Inverted** when using:
 - Tru Count Clutches
 - Tru Count Liqui-Block valves
 - John Deere row clutches
- Set the **Valve On / Off Latency**: If required, set a delay (in seconds) between when you send a command to the sprayer and when it starts spraying.
- Set **Turn Off When Stopped**: This controls whether the section stays on or turn off when the GPS speed is 0 mph

3. Tap **OK**.

Setting up the Sections



1. In the *Configuration* screen, select *EZ-Boom* and then tap **Setup**.
2. Tap the *Sections* tab:
3. Select the number of sections, and then set the width of the sections.
4. If required, tap the **Left Fence Nozzle** and **Right Fence Nozzle** buttons to enable them (the nozzles are at the ends of the boom).

Setting the Application Rate

1. Select the *Rate* tab:

2. Select *Rate 1* and *Rate 2*. These are the value that will be used when the Rate switch in EZ-Boom is set to Rate 1 or Rate 2.
3. Enter a *Rate Increment*. This sets the value the rate will change by when you press the increase or decrease button or switch.
4. Select whether you want to turn *Rate Snapping* on or off. This controls if you want the displayed rate to be shown as on-target when within 10% of the target rate.
5. Tap **OK**.

Setting Tank Volume

1. Select the *Tank* tab:

2. Select the *Volume* field and then use the touch screen to enter a new value.
3. Enter the *Tank Capacity* - this is the size of the sprayer tank.
4. Enter the *Warning Level* - this is the volume at which the display warns that the tank volume is getting low.
5. Tap **OK**.

Valve calibration


1. In the *Configuration* screen, select *EZ-Boom* and then tap **Calibrate**.
2. Select *Valve Calibration* and then tap **Start**:

Note: Reference the *EZ-Boom 2010 Getting Started Guide Definitions* chapter for a list of default values to use for the *Valve Type*, *Response 1* and *Response 2* and *Threshold* fields.

3. In the *Valve Type* field, select the type of control valve used on the application, for example *In-line Servo*.
4. In the *Response 1 / Response 2* fields, adjust to increase or decrease the response of the valve. A larger value means a faster, less accurate response. Response 1 is used for larger changes and Response 2 for smaller changes. The threshold value defines when to use Response 1 or Response 2.
5. Tap **OK**.

Flow Calibration

1. Select *Flow Calibration* and then tap **Start**:



The screenshot shows the 'EZ-Boom Flow Calibration' dialog box. It contains several input fields and a dropdown menu:

- Close Valve on Zero Flow:** A dropdown menu set to 'Yes'.
- Flow Control Delay:** A text input field containing '0 s'.
- Min Flow:** A text input field containing '0.0 gal/min'.
- Allowable Error:** A text input field containing '2 %'.
- Flowmeter Calibration:** A text input field containing '700 gal'.


At the bottom of the dialog, there is a 'Recalibrate' button and two main buttons: 'Cancel' on the left and 'OK' on the right.

Note: You must complete the Flow Calibration before application.

2. Enter the *Flow Control Delay* in seconds.
3. Enter the existing *Flowmeter Calibration* number provided with the flowmeter.
4. Tap **OK**.

Adjusting the Application Rate


Press the plus and minus buttons on the *EZ-Boom* tab to increase or decrease the rate on the go:



The +/- switch on the EZ-Boom controller will also adjust the rate on the go.

Getting started in a field

1. Tap .
2. Select or create client, farm, field, and event names for the operation and then tap **OK**




The screenshot shows the 'Field Selection' dialog box. It contains several input fields and buttons:


- Client:** 'Smith' (with a 'New' button)
- Farm:** 'Home Place' (with a 'New' button)
- Field:** 'South 240' (with a 'New' button)
- Event:** 'Plant' (with a 'New' button)

Below these fields are buttons for 'Event Attributes' and 'Variety Setup'. At the bottom, there is a 'Cancel' button on the left and an 'OK' button on the right.

3. On the *Run* screen, tap **Swaths**. The *Swaths management* screen appears.



4. From the drop-down box, select the pattern type (AB, Curve, Pivot, or Headland) and then tap **New Straight**:



The screenshot shows the 'Swath Management' dialog box. It contains several input fields and buttons:


- Swaths:** A dropdown menu set to 'AB'.
- As Heading:** A text input field containing '0.00°'.

At the bottom, there are buttons for 'Import', 'Delete', 'Access Paths', 'Cancel', 'New Straight', and 'Load'.


with the AgGPS® EZ-Boom® 2010 System Quick Reference Card

Note: Use the Headland pattern when you do not want the application to operate outside the field boundary. If you select this pattern, the EZ-Boom system shuts off boom sections outside the field boundary. If you select another pattern, the EZ-Boom system shuts off sections only when it is in a covered area.

- On the Run screen, tap **Set A** and follow the on-screen instructions to finish the pattern.



- Once the new swath has been created, tap **Engage** to engage the Autopilot or EZ-Steer® system. The Ez-Boom sections are controlled manually by the switches on the EZ-Boom system.



Use the switches as follows:



- Tap the Increase/Decrease switch to increase or decrease the rate from the run screen. You do not need to tap the Increase/Decrease switch on the EZ-Boom system.
- Tap the Tank button to open the Tank tab where you can select quick refill options.

Boom sections

If the section is ...	Then ...
Red 	Section switches or the master switch are shut off on the EZ-Boom controller and no power is outputted to the sections.
Grey 	Sections are in a covered area or the EZ-Boom controller is reading zero flow from the flow meter. Power may or may not be sent out to the sections.
Green 	Sections are on and the EZ-Boom controller is outputting power to turn the section on.



P/N 93020-81-E03